

Print		
Maximum Printing Resolution	4800 (horizontal)* ¹ x 1200 (vertical) dpi	
Print Head / Ink	Type:	FINE Cartridge
	Total Number of Nozzles:	1,792 nozzles
	Ink Droplet Size (minimum):	2pl
	Ink Cartridge:	PG-740, CL-741, (PG-740XL, CL-741XL - Optional)
Print Speed* ² : Based on ISO / IEC 24734. Click here for summary report Click here for Document Print and Copy Speed Measurement Conditions	Document: Colour ESAT / Simplex:	Approx. 5.7ipm
	Document: B/W: ESAT / Simplex:	Approx. 9.9ipm
	Photo (4 x 6"): PP-201 / Borderless:	Approx. 44secs.
Printable Width	Bordered:	Up to 203.2mm (8inch)
	Borderless:	Up to 216mm (8.5inch)
Printable Area	Borderless Printing* ³ :	Top / Bottom / Right / Left margin: each 0mm (Supported Paper Size: A4 / Letter / 4 x 6" / 5 x 7" / 8 x 10")
	Bordered Printing:	Top margin: 3mm, Bottom margin: 5mm, Left / Right margin: each 3.4mm (Letter / Legal: Left: 6.4mm, Right: 6.3mm)
	Bordered Auto 2-sided printing	Top margin: 5mm, Bottom margin: 5mm, Left / Right margin: each 3.4mm (Letter / Legal: Left: 6.4mm, Right: 6.3mm)
Recommended Printing Area	Top Margin:	32.5mm
	Bottom Margin:	33.5mm
Paper Size	A4, A5, B5, Letter, Legal, 4 x 6", 5 x 7", 8 x 10", Envelopes(DL, COM10), Custom size (width 89 - 215.9mm, length 127 - 676mm)	
Paper Handling (Front Tray) (Maximum Number)	Plain Paper	A4, A5, B5, Letter = 100, Legal = 10

	High Resolution Paper (HR-101N)	A4 = 80
	Photo Paper Pro Platinum (PT-101)	4 x 6" = 20, A4 = 10
	Photo Paper Plus Glossy II (PP-201)	4 x 6" = 20, A4 = 10
	Photo Paper Pro Luster (LU-101)	A4 = 10
	Photo Paper Plus Semi-Gloss (SG-201)	4 x 6" = 20, A4, 8 x 10" = 10
	Glossy Photo Paper "Everyday Use" (GP-508)	4 x 6" = 20, A4 = 10
	Glossy Photo Paper "Everyday Use" (GP-601)	4 x 6" = 20, A4 = 10
	Matte Photo Paper (MP-101)	4 x 6" = 20, A4 = 10
	Envelope	European DL / US Com. #10 = 5
Support Media for Auto 2-sided printing	Type:	Plain Paper
	Size:	A4, Letter
Paper Weight	Front Tray:	Plain Paper: 64 - 105g/m ² , Canon specialty paper: max paper weight: Approx. 300g/m ² (Photo Paper Pro Platinum PT-101)
Ink End Sensor	Dot count	
Print Head Alignment	Manual	
Scan ^{*4}		
Scanner Type	Flatbed	
Scanning Method	CIS (Contact Image Sensor)	
Optical Resolution ^{*5}	1200 x 2400dpi	
Selectable Resolution ^{*6}	25 - 19200dpi	
Scanning Bit Depth (Input / Output)	Grayscale:	16 bits / 8 bits

	Colour:	48bits / 24bits (RGB each 16bits / 8bits)
Line Scanning Speed* ⁷	Grayscale:	1.2 ms/line (300dpi)
	Colour:	3.5 ms/line (300dpi)
Scanning Speed* ⁸	Reflective: A4 Colour / 300dpi	Approx. 14secs.
Maximum Document Size	Flatbed:	A4 / Letter (216 x 297mm)
Copy		
Maximum Document Size	A4 / Letter (216 x 297mm)	
Compatible Media	Size:	A4, Letter, 4 x 6" (Photo Paper Plus Glossy II, PP-201)
	Type:	Plain Paper Photo Paper Plus Glossy II (PP-201) (4 x 6")
Image Quality	Plain Paper:	Draft, Standard
Copy Speed* ⁹ Based on ISO / IEC 29183. Click here for summary report Click here for Document Print and Copy Speed Measurement Conditions	Document: Colour: sFCOT / Simplex:	Approx. 22secs.
	Document: Colour: sESAT / Simplex:	Approx. 2.7ipm
Multiple Copy	Black / Colour	1 - 21 pages
Network		
Interface	Wireless LAN b/g/n, USB 2.0 Hi-Speed	
Wireless LAN	Network Type:	IEEE802.11n / IEEE802.11g / IEEE802.11b (infrastructure mode)
	Frequency Band:	2.4GHz
	Range:	indoor 50m (depends on the transmission speed and conditions)
	Security:	WEP64 / 128bits, WPA-PSK (TKIP / AES), WPA2-PSK (TKIP / AES)
Direct connection (Wireless LAN)	Available (Access Point Mode only)	
System Requirements (Please visit www.canon-asia.com to check OS compatibility and to download the latest driver updates.)	Windows:	Windows 8 / Windows 7 / Window Vista / Windows XP
	Macintosh:	Mac OS X v10.7.5 or later

Apple AirPrint	Available	
Mopria	Available	
Canon Print Service Plug-In (on Android OS)	Available	
Google Cloud Print	Available	
PIXMA Cloud Link (from smartphone or tablet)	Available	
Canon PRINT Inkjet/SELPHY App (for iOS / Android OS) Canon Easy-PhotoPrint (for Windows RT OS)	Available	
PictBridge	Wireless LAN:	Available
General		
Operating Environment* ¹⁰	Temperature:	5 - 35°C
	Humidity:	10 - 90% RH (no dew condensation)
Recommended Environment* ¹¹	Temperature:	15 -30°C
	Humidity:	10 - 80% RH (no dew condensation)
Storage Environment	Temperature:	0 - 40°C
	Humidity:	5 - 95% RH (no dew condensation)
Acoustic Noise (PC Print)	Photo (4 x 6")* ¹²	Approx. 43.5dB(A)
Power	AC 100 - 240V, 50 / 60Hz	
Power Consumption	OFF:	Approx. 0.1W
	Standby (scanning lamp is off) (Wireless LAN connection to PC):	Approx. 1.4W
	Standby (all ports connected, scanning lamp is off):	Approx. 1.4W

	Copying*13: (Wireless LAN connection to PC):	Approx. 16W
Environment	Regulation:	RoHS (EU, China), WEEE (EU)
	Eco-Label:	Energy Star, EPEAT
Dimension (W x D x H)	Approx. 449 x 304 x 152mm	
Weight	Approx. 5.4kg	

Specifications are subject to change without notice.

*1 Ink droplets can be placed with a pitch of 1/4800 inch at minimum.

*2 Document print speeds are the averages of ESAT in Office Category Test for the default simplex mode, ISO / IEC 24734.
Photo print speed is based on the default setting using ISO / JIS-SCID N2 on Photo Paper Plus Glossy II and does not take into account data processing time on host computer.
Print speed may vary depending on system configuration, interface, software, document complexity, print mode, page coverage, type of paper used etc.

*3 Paper types NOT supported for borderless printing are as follows: Envelope, High Resolution Paper, T-Shirt Transfer, Photo Stickers.

*4 TWAIN driver (ScanGear) is based on the TWAIN specification V1.9 and requires the Data Source Manager comes with the operating system.

*5 Optical resolution is a measure of maximum hardware sampling resolution, based on ISO 14473 standard.

*6 Increasing the scanning resolution will limit the maximum possible scanning area.

*7 The fastest speed in Hi-Speed USB on Windows PC. Transfer time to computer is not included.

*8 Colour document scan speed is measured with ISO / IEC 29183 Target A.
Scan speed indicates the time measured between pressing the scan button of the scanner driver and the on-screen status display turns off.
Scan speed may vary depending on system configuration, interface, software, scan mode settings and document size etc.

*9 Copy speeds are the average of sFCOT and sESAT, ISO / IEC 29183.
Copy speed may vary depending on document complexity, copy mode, page coverage, type of paper used etc. and does not take into account warm-up time.

*10 The performance of the printer may be reduced under certain temperature and humidity conditions.

*11 For the temperature and humidity conditions of papers such as photo paper, refer to the paper's packaging or the supplied instructions.

-
- *12 When printing ISO / JIS-SCID N2 on 4 x 6" Photo Paper Plus Glossy II using default settings.
-
- *13 Copy: When copying ISO / JIS-SCID N2 (printed by inkjet printer) on A4 size plain paper using default settings.
Print: When printing ISO / JIS-SCID N2 (printed by inkjet printer) on A4 size plain paper using default settings.
-

Disclaimer

- You need to install ink tanks or ink cartridges of all colours whether you perform black and white printing or colour printing. If any one of the ink tanks or ink cartridges is not installed, an error occurs and you cannot perform printing.
-
- Depending on the paper or the print settings, colour ink may be consumed even when you print a document in black or perform printing in black and white. When any one of the colours of ink has run out, you need to replace the ink tank or ink cartridge.
-
- When you use the Canon printer for the first time after you install the bundled ink tanks, the printer consumes a small amount of ink in the amount to enable printing by filling the nozzles of the Print Head with ink. For this reason, the number of sheets that can be printed with the first ink tanks is fewer than the succeeding ink tanks.
-
- The printing costs described in the brochures or websites are based on the consumption data from not the first ink tank /ink cartridge but the succeeding ink tank /ink cartridge.
-
- To keep printer's performance, Canon printer performs cleaning automatically according to its condition. When the printer performs cleaning, a small amount of ink is consumed. In this case, all colours of ink may be consumed.
[Cleaning function]
The cleaning function helps the printer to suck air bubbles or ink itself from the nozzle and thus prevents print quality degradation or nozzle clogging.
-
- The repairing parts for printers will be available five years after production is discontinued. Depending on your model, we may ask you to replace it with a new one, or one with almost the same performance as a maintenance service. In this case, it may be that you cannot use supplies or accessories for your model or the compatible OS will be changed.
-
- The warranty term for free repair varies from country to country and starts from the date of purchase. Free repair does not apply to supplies (paper or ink tanks / cartridges / print head) even within the warranty term.
-
- To obtain good printing quality, use up ink within six months after opening.
-
- Regarding a solution to a problem caused by using non-genuine ink cartridges or ink tanks (including ones supplemented with non-genuine ink by making a hole in the cartridge or so), a fee will be charged even within the warranty term. Keep this in your mind when you use non-genuine ink.
-
- If you use non-genuine ink cartridges or ink tanks (including ones supplemented with non-genuine ink by making a hole in the cartridge or so), they may have a negative effect on the performance of the printer or the printing quality may be reduced. In addition, though it is a rare case and does not present a safety hazard, it is reported that a print head will become heated or smoke will be emitted from it due to an ingredient not contained in genuine Canon ink. (Note that this does not apply to all non-genuine ink.)
-

-
- The following functions are available only on printers that use genuine Canon ink for all colors and support these functions. For supported functions, see the product specifications section for each model.
 - Printing CREATIVE PARK PREMIUM content via My Image Garden, Easy-PhotoPrint+, or PIXMA Cloud Link
 - Using the following applications via PIXMA Cloud Link
 - – Scan to E-mail
 - – Attach to Webmail
 - – Scan to Office document
 - – Scan and Remote Print
 - – Saving scanned images to Dropbox, Google Drive, OneDrive, Evernote, OneNote, Access to SlideShare

-
- A printer with a fax function stores the following fax data in printer's memory:

- Faxes not printed out due to conditions such as ink running out.

- Faxes in the send queue.

If you disconnect the power cord, the date and time settings are reset and faxes stored in the printer's memory will be deleted. Before you disconnect the power cord, confirm that faxes you need to keep have already been printed or sent.

-
- If you will be installing the Canon printer driver on Mac OS X and using the printer through a network connection, you can select [Bonjour] or [canonijnetwork] in the [Add Printer] dialog. If [Bonjour] is selected, remaining ink level messages may differ from those indicated by [canonijnetwork]. [canonijnetwork] is not displayed if the Canon printer driver is not installed. Access our web site through the Internet and download the latest printer driver for your model. Canon recommends you to use [canonijnetwork] for printing.

-
- For Malaysia, MG3670 is only available in red colour.
-